












Writing Tab

No	Series	Image	Relay Height	Part No.	Fitting Socket
9	CSR (PI)			WE-PI	<ul style="list-style-type: none"> ▪ CSR-S35/50F2 ▪ CSR-S35/50F3 ▪ CSR-C35/50F3 ▪ CSR-S50F3-T
10	CST (PYF)			WE-PYF	<ul style="list-style-type: none"> ▪ CST-S08/11/14F2 ▪ CST-S08/11/14F3 ▪ CST-C08/14F3 ▪ CST-S14F2-H ▪ CST-S14F3-T
11	CLR			WE-CLR	<ul style="list-style-type: none"> ▪ CLR-P05 ▪ CLR-S05F3 ▪ CLR-C05F3
12	CST (PYF)			WA-PYF	<ul style="list-style-type: none"> ▪ CST-A08/14F2-W ▪ CST-B08/14F2-W

Jump link (Contact Bridge)

13	CST (PYF)			CB-PYF-5	<ul style="list-style-type: none"> ▪ CST-S08/11/14F2 ▪ CST-S08/11/14F3 ▪ CST-C08/14F3 ▪ CST-S14F2-H ▪ CST-S14F3-T
14	CSR (PI)			CB-PI-8	<ul style="list-style-type: none"> ▪ CSR-S35/50F2 ▪ CSR-S35/50F3 ▪ CSR-C35/50F3 ▪ CSR-S50F3-T
15					
16	CST (PYF)			CB-PYF-10	<ul style="list-style-type: none"> ▪ CST-S08/11/14F2 ▪ CST-S08/11/14F3 ▪ CST-C08/14F3 ▪ CST-S14F2-H ▪ CST-S14F3-T
17	CLR			CB-CLR-20	<ul style="list-style-type: none"> ▪ CLR-S05F3 ▪ CLR-C05F3
18	CSR (PI)			CB-PI-CC	<ul style="list-style-type: none"> ▪ CSR-C35/50F3
19	CST (PYF)			CB-PYF-CC	<ul style="list-style-type: none"> ▪ CST-C08/14F3

Insulation Sheet

20	CLR				<ul style="list-style-type: none"> ▪ CLR-S05F3 ▪ CLR-C05F3
----	-----	---	--	--	--